

Comfort Stance

Cleaning & Maintenance Instructions

The following cleaning & maintenance instructions are recommended to ensure the product maintains its desired appearance and effective performance, as well as ensuring a long life span for the product.

Dry Areas

1. Shake dirt from mat and remove mat from service area.
2. Vacuum or sweep dirt from service area.
3. If needed, flush both sides of mat with warm water to remove remaining dirt.
4. Allow mat to dry flat before placing it back into service.

Wet Areas

1. Hose both sides of mat with warm water.

Periodic Maintenance

Severely soiled matting can be restored to a high level of appearance with one of the following cleaning methods:

Pre-spray mat with a low foaming, all-purpose cleaner. (For heavy grease buildup, use a water-based cleaner-degreaser.) Allow cleaning solution to dwell on mat for 3 to 5 minutes. Brush with a nylon bristle scrub brush. Flush mat with hot water and allow to dry flat before placing it back into service.

-OR-

Clean the mat using a high-pressure washer with a low foaming general purpose cleaner. Flush mat with hot water and allow to dry flat before placing it back into service.